



WESTERN INTERLOCK INC.

Paving Stone and Retaining Wall Systems Made for the Northwest.



FIRE PIT INSTALLATION

westerninterlock.com

Fire Pit Installation

Western Interlock's kits are all-inclusive and are designed so no cuts are needed for a quick and easy installation. We've done all the work so you can achieve professional results! All you need to follow these directions are a shovel, rubber hammer, a level, gravel and a caulking gun.

STEP 1: Design

Draw a print of your project to determine what you will need. Find a location that is clear and open, free from overhanging branches; as well as 50' from any building for safety. Spray paint fire pit outline on the ground with marking paint.



STEP 2: Excavate and add base

A solid gravel base works best to support the weight of the fire pit blocks. Excavate 3" and fill with $\frac{3}{4}$ minus gravel. Make sure the base is level and compact using a hand tamper, or to get maximum compaction, use a vibratory plate compactor. This will insure that the fire pit is level and will not settle.



STEP 3: Laying the bottom course

The first course will lie on the gravel base. After each block is laid, make sure each block is level in each direction. Use a plastic dead blow hammer to settle the block into the base. If the block needs to be raised, add gravel under the low side of the block and check the block for levelness. Take a longer level and check the fire pit from side to side. Use a 2x4 board to extend your level if necessary. The outside edges of the fire pit blocks should all be touching, and the inside will have small gaps between each block.



	Diameter	Courses	Caps
Tegula Garden Wall™ Small Fire Pit	40"	2	Included
Chateau Wall™ Medium Fire Pit	50"	3	Optional

STEP 4: Laying the second or third courses

After the first course is set and leveled, use the adhesive cartridge supplied with the kit. Cut the end about half way down the nozzle and puncture the membrane in the end of the cartridge. Make sure the blocks are clean and as dust free as possible using a broom. Apply four quarter size dots of adhesive in the corner of each block of the first course, leave some space so it does not squeeze out the sides (see photo). Place blocks on top of the first course, offsetting the lines for better appearance.



STEP 5: Place the caps (optional)

After the second course is placed and adjusted, make sure the caps are clean and as dust free as possible. Apply four quarter size dots to the top of the second course exactly as you did for the first course. Place the caps around the top of the fire pit and adjust them to fit as neatly as possible. You will have to adjust the spaces between each cap to make the appearance look best. To achieve an easy cap effect with Chateau Wall™ Beveled, simply add one block to the course. This adds 2" to the diameter, creating the appearance of a cap.



STEP 6: Enjoying the fire pit

Let the adhesive cure for 24 hours before use. Put your feet up and warm your toes! Get out the marshmallows and hot dogs. Have a friendly conversation with family and friends and check out the stars. (If it's not raining!)



There is a Western Interlock dealer near you!

We invite you to stop by any of our retail facilities or dealerships to speak with a knowledgeable sales person, and to see our product in person.

Oregon

BANDON SUPPLY
541.347.2662 • Bandon

BEST BUY IN TOWN
503.645.6665 • Hillsboro

COPELAND LUMBER
541.997.8474 • Florence

DOUGLAS COUNTY FARMER'S CO-OP
800.452.0981 • Roseburg

LANE FOREST PRODUCTS
541.345.9085 • Eugene

LONG BROTHERS' BUILDING SUPPLY
503.981.4041 • Woodburn

VALLEY LANDSCAPE CENTER
503.692.0606 • Tualatin

BARK BOYS
503.378.7379 • Salem

CEMENT PRODUCTS
541.548.5910 • Redmond

COPELAND LUMBER
541.265.6640 • Newport

EASTERN OREGON RENTAL & SALES
541.963.8300 • La Grande

LANE FOREST PRODUCTS
541.345.9085 • Springfield

SCAPPOOSE SAND & GRAVEL
503.543.8821 • Scappoose

BEAR VALLEY NURSERY
541.996.2327 • Lincoln City

CLACKAMAS LANDSCAPE SUPPLY
503.656.2891 • Oregon City

COPELAND LUMBER
541.563.3166 • Waldport

KLAMATH STONE & MASONRY SUPPLY
541.273.7036 • Klamath Falls

LEAVE YOUR MARK
541.535.3445 • Phoenix

STONE DEPOT
503.465.1502 • Gresham

Washington

BLAKE TILE & STONE
360.681.2877 • Sequim

NKS STONES, INC
206.767.9776 • Seattle

SWANSON BARK
360.414.9663 • Longview

WESTERN MATERIALS
509.547.3301 • Pasco

WESTERN MATERIALS
509.575.3000 • Yakima

DOWELL COMPANY
253.852.1700 • Kent

NORTH BEND LANDSCAPE SUPPLY
425.888.6502 • North Bend

TACOMA WINSUPPLY
253.272.8445 • Tacoma

WESTERN MATERIALS
360.984.5097 • Vancouver

GIBSONS NURSERY
509.928.0973 • Spokane

SIMPLY ROCKS
360.863.3975 • Snohomish

UNION HILL HARDSCAPE & BRICK
425.318.5102 • Redmond

WESTERN MATERIALS
509.886.5182 • Wenatchee

WESTERN INTERLOCK RETAIL FACILITIES:

10095 Rickreall Rd, Rickreall, OR 97101

9145 Fasset St., Olympia, WA 98512



Paving Stone & Retaining Wall Systems Made for the Northwest.

503.623.9084 OR
360.878.9301 WA

westerninterlock.com